


# HP SureStore E Disk Array 12H

## CONTROL PANEL QUICK REFERENCE GUIDE



## USING THE CONTROL PANEL

Use the control panel to perform disk array configuration tasks and view configuration settings. Refer to the CONTROL PANEL MENU MAP on the other side of this page:

1. Press MENU to select the Main Menu.
2. Press + or — to scroll to a menu.
3. Press ENTER to select a menu.
4. Press + or — to scroll to a menu item.
5. Press ENTER to select a menu item.
6. Press + or — then press ENTER to select values for a task, enable/disable, and confirm/cancel.

**Note:** ± means more information is available on the control panel display

Customer part number:

C5445-90906

Printed in U.S.A.

June 1999

Edition 4

E0699

Part Number



\*A3700-96018\*

CONTROL  
PANEL  
MENU MAP

